


Ambiane[®] HP111 Recessed



QR code for user manual



USER MANUAL

Version 2.4

Table of contents

1. Attention.....	3
2. Fixture exterior view.....	4
3. Installation	5
3.1. DMX and DALI address setting and control.....	12
3.2 0-10V control	13
4. RDM	13
4.1 Example of Control panel in RDM manager.....	14
5. DMX protocols	15
6. Technical specifications	17
7. Photometric diagrams	22
8. Cleaning and maintenance	23
8.1 Software update	23
8.2 Disposing of the product	24

1. Attention

The unit must be installed by a qualified electrician in accordance with all national and local electrical and construction codes and regulations.

The unit was designed for indoor use only.

This unit falls under protection class III

Do not install the unit near highly inflammable liquids or materials.

Do not allow anything to rest on the unit.

Do not install the unit near an open flame.

Do not install the unit in dirty, dusty or badly ventilated location.

Avoid looking directly into the light beam at close range!

A ceiling (structure) intended for installation of the unit(s) must safely hold at least 5 times the weight of the unit(s) fastened on it.

Sufficient air accessing to the housing of the unit has to be ensured, there must not be any heat or anti-noise insulation).



Unsuitable for covering by heat insulation material

The product (covers and cables) must not be exposed to a high frequency electromagnetic field higher than 3V/m.


Immunity of the equipment is designed according to the standard EN 55035 Electromagnetic compatibility of multimedia equipment - Immunity requirements.

Emission of the equipment complies with the standard EN55032 Electromagnetic compatibility of multimedia equipment – Emission Requirements according to class B.


This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

2. Fixture exterior view



Version with mounting yoke




3. Installation

The Ambiane HP111 Recessed must be installed by a qualified electrician in accordance with all national and local electrical and construction codes and regulations.


Always switch off power supply of the control unit before connecting or disconnecting the control unit or the LED unit.

The lower ceiling (or another structure) intended for installation of the Ambiane(s) HP111 Recessed must safely hold at least 5 times weight of the Ambiane(s) HP111 Recessed placed on it.

1. Prepare a circular opening in the lower ceiling.




2. Fasten the control unit (1) on the ceiling by means of two holes in the housing of the control unit.



Ambiane HP111 Recessed without mounting yoke:


3. Remove the frame with reflector (3) from the Ambiane HP111 housing (4) by pushing and turning the frame with reflector (3) counter-clockwise. The frame with reflector (3) is fastened in the housing by means of four locks (2).



- 4.** Install the terminal block (5) on the supply cable connect it to the PCB RB 3729 of the control unit (1).
- 5.** Install the terminal block (6) on the DMX cable and connect it to the PCB RB 3729 of the control unit (1).
- 6.** Install the terminal block (7) on the LED unit cable and connect it to the PCB RB 3729 of the control unit (1).
- 7.** Install another terminal blocks on cables according to requirements of current installation.

Ambiane HP111 Recessed

Example of connection:




The green LED on the PCB signals way of DMX address setting:
 LED lights-DMX address is set by means of the DIP switch.
 LED does not light- DMX address is set by means of RDM.

The DIP switch (9) is accessible by the aperture (8) in the cover of the control unit (1).

LED unit connection (cable LSYY 5x18 AWG)

Connector	+	A	B	-
Function	LEDs +	Data A	Data B	LEDs -
Colour of wire	Red	White	Blue	Black

Strip these lengths for cable connections



Primary power connection

Connector	Vcc	0V
Function	Power +	Power -

Recommended diameters of conductors with respect to distance between the Control unit and the power supply (e.g. Ambiane Power HP):

Distance/cable length	25 m	50 m	75 m	100 m
Diameters of conductors	0.5 mm ²	1 mm ²	1.5 mm ²	2 mm ²

Secondary power connection

Connector	Vcc	0V
Function	Power +	Power -

DMX connection

Connector	D+	D-	0V
Function	Data +	Data-	Data ground (shielding)

0-10V connection

Connector	D+	0V
Function	+10V	0V

DMX connectors are used for 0-10V control

Primary and secondary power.

The primary power input serves for a standard power (e.g. Ambiane Power HP).

The secondary power input serves for a backup power (in case that primary power failed) – emergency mode.

If both power inputs are under voltage, the primary power has a priority and the secondary power is disabled. In case of primary power loss, the secondary power is enabled.

If the fixture is supplied via the secondary power, the light output of the fixture is a white colour 3200K (for RGBW, TW and TD variants only).

Max. operating time for secondary power is 3 hours (max. power consumption is reduced to 20 W).

8. Set the DIP switch (9) according to your operation mode. This DIP switch is accessible by aperture (8) in the cover of the control unit (1).

The fixture can be controlled by one of the following methods: DMX 512



DALI

0-10V (PW or TD version only)

The fixture is equipped with two DMX and DALI connection blocks (on the PCB RB 3729) for easy connection to a DMX or DALI chain (In/Out method).

9. After connecting needed cables to the control unit, insert the LED unit (4) into prepared hole in the lower ceiling and screw two adjusting screws (11) in order to slide and support the levers (12) against surface (lower ceiling).


Ambiane HP111 Recessed




10. Insert the frame with reflector (3) to the Ambiane HP111 housing (4) and push and turn it clockwise until it snaps into locks (2) in the Ambiane HP111 housing (4).

Important. The positions of the triangle marks (13) have to be aligned before inserting and turning the frame with reflector (3).

Ambiane HP111 Recessed



Ambiane HP111 Recessed




Ambiane HP111 Recessed with mounting yoke:

4. Insert the LED unit (6) with control unit (1) into prepared hole in the lower ceiling, the control unit has to be lying (or fastened) on a non-flammable flat surface.
5. Fasten the mounting yoke to the ceiling.

3.1. DMX and DALI address setting and control

The DIP switch on the control PCB (RB3729) allows you to set DMX address and run a test light.



DIP 10 - if it is switched to ON=test light (the fixture lights at 3200K (for RGBW and TW version))

DIP 11 - has to be switched to OFF position to receive DMX 512 and DALI, position ON=0-10V control

Note: If DIP 11=OFF (fixture is controlled by DMX and DALI), the last coming command switches the fixture to the corresponding operation mode (DMX operation by a DMX command, DALI operation by a DALI command). E.g. the fixture stays in a DALI operation and last coming command is a DMX command which switches the fixture to DMX operation. Next command is a DALI command and switches the fixture to the DALI operation etc.

If you need the permanent DALI operation, you have to send a DALI command 8 to the fixture.

DMX control


The DMX start address, is the first channel used to receive instructions from the DMX controller. The address may be any channel from 1 to 512. DMX address can be set either by DIP switch or by RDM. DMX address set by RDM overwrites address set by DIP switch and vice versa. The green LED on PCB signals way of DMX address setting:

LED lights-DMX address is set by means of the DIP switch.

LED does not light-DMX address is set by means of RDM.

The DIP 11 has to be set to OFF position.

Example of DMX addresses:



DALI control

Addressing of the fixture has to be made by means of an external DALI controller.

If you need to start the permanent DALI control of the fixture (fixture will not respond to DMX commands), the external DALI controller has to send activating command (8=ON).

If you need to stop the permanent DALI control of the fixture, the external DALI controller has to send deactivating command (0=OFF).

3.2 0-10V control

DIP 11 has to be set in ON position. 0-10V operation has priority to DALI and DMX commands. The option is applicable for the PW and TD version of the Ambiane HP111 only.

4. RDM

This fixture supports RDM operation. RDM (Remote Device Management) is a bi-directional communication protocol for use in DM X512 control systems, it is the new open standard for DMX512 device configuration and status monitoring.

RDM allows you to set a DMX address, select DMX mode, readout software version of the fixture etc. It is also used for fixture software update by means of the Robe Uploader

RDM model ID for the Ambiane HP111 Recessed 0x0114.

Parameter ID	Discovery command	SET command	GET command
DISC_UNIQUE_BRANCH	*		
DISC_MUTE	*		
DISC_UN_MUTE	*		
DEVICE_INFO			*
SUPPORTED_PARAMETERS			*
SOFTWARE_VERSION_LABEL			*
DMX_START_ADDRESS		*	*
IDENTIFY_DEVICE		*	*
DEVICE_MODEL_DESCRIPTION			*
MANUFACTURER_LABEL			*
DEVICE_LABEL		*	*
DMX_PERSONALITY		*	*
DMX_PERSONALITY_DESCRIPTION			*
SENSOR_VALUE		*	*
SENSOR_DEFINITION			*

SLOT_INFO			*
SLOT_DESCRIPTION			*
DEFAULT_SLOT_VALUE			*
PARAMETER_DESCRIPTION			*

4.1 Example of Control panel in RDM manager

Device: 52:53-01:14:02:d7

Device model description: [Ambiane HP RGBW](#)

Device label:

☐ DMX512 setup

DMX512 footprint: [12](#)

Current personality:

Personalities count: [5](#)

DMX address:

☐ Power/Lamp setup

☐ Configuration

Factory defaults:

☐ Control

Identify device:

☐ Display settings

☐ Manufacturer PIDs

Power Switch: [\(hex\)](#)

Dmx lost: [\(hex\)](#)

Dmx hold: [\(hex\)](#)

Manufacturer PIDs:

DMX hold [00]- last received DMX values are held in case of DMX signal lost.

DMX hold [01]- option "DMX lost" is activated and influences behaviour of the fixture at DMX signal lost.
Default value is [00].

DMX lost [00]- the fixture lights on full power (dimmer open) at DMX signal lost.

DMX lost [01]- the fixture close light output at DMX signal lost.

Default value is [00].

Power Switch [00]- the fixture uses primary power.

Power Switch [01]- the fixture uses secondary power.

Default value is [00].

5. DMX protocols

Variant RGBW, version 1.0

Mode 1 Channel	Mode 2 Channel	Mode 3 Channel	Mode 4 Channel	Mode 5 Channel	DMX value	Function	Type of control
1	1	1	-	1	0-255	Red Red LEDs saturation control (0-->100%)	proportional
-	-	2	-	-	0-255	Red Fine Red LEDs saturation control (0-->100%)	proportional
2	2	3	-	2	0-255	Green Green LEDs saturation control (0-100%)	proportional
-	-	4	-	-	0-255	Green Fine Green LEDs saturation control (0-->100%)	proportional
3	3	5	-	3	0-255	Blue Blue LEDs saturation control (0 -->100%)	proportional
-	-	6	-	-	0-255	Blue Fine Blue LEDs saturation control (0-->100%)	proportional
4	-	7	-	4	0-255	White White LEDs saturation control (0-->100%)	proportional
-	-	8	-	-	0-255	White Fine White LEDs saturation control (0-->100%)	proportional
-	-	9	1		0 1-127 128 129- 255	Green correction Uncorrected white Minus green --> uncorrected white Uncorrected white (128=default) Uncorrected white --> Plus green	step proportional step proportional
-	-	10	2		0 1-10 11-20 21-255	Colour temperature correction (CTC) No function (0=default) Tungsten dimming 2700 K Tungsten dimming 3200 K Colour temperature changing 2700 K--> 6500 K	step step step proportional
-	-	11	3	5	0-255	Dimmer Light intensity coarse (0-->100%)	proportional
-	-	12	-	6	0-255	Dimmer Fine Light intensity fine (0-->100%).	proportional

DMX mode has to be set by RDM.

Ambiane HP111 Recessed

Variant TW, version 1.1

Mode 1 Channel	Mode 2 Channel	Mode 3 Channel	Mode 4 Channel	DMX value	Function	Type of control
1	-	1	-	0-255	White colour selection White from 2700K-->4000K	proportional
-	1	-	1	0-255	Warm White Warm white LEDs saturation control (0-->100%)	proportional
-	2	-	2	0-255	Cool White Cool white LEDs saturation control (0-->100%)	proportional
2	3	2	3	0-255	Dimmer Light intensity (0-->100%)	proportional
-	-	3	4	0-255	Dimmer Fine Light intensity fine (min-->max)	proportional

Variant TD, PW version 1.0


Mode 1 Channel	Mode 2 Channel	DMX value	Function	Type of control
1	1	0-255	Dimmer Light intensity coarse (0-->100%)	proportional
-	2	0-255	Dimmer Fine Light intensity (0-->100%)	proportional

6. Technical specifications

Nominal input voltage:	48V DC
Input voltage range:	44-50V DC
Max. power consumption (primary power):	75W
Max. power consumption (secondary power):	20W
Max. operating time for secondary power:	3 hours
Light source:	High Power LED module
Beam angle:	20°, 40°, 60°, 80°
Projected lumen maintenance:	L90B10 >90.000 hrs, Ta = 25°C / 77°F °F)
Colour variants:	RGBW (W - 2700K or 4000K), PureWhite, Tunable White, Tungsten Dim
Colour temperature of white:	PW 2700 K or 4000K, TW 2700 - 4000K
Control:	DMX, DALI , RDM, 0-10V
Settings/Addressing:	DIP Switch, RDM
DMX channels (RGBW variant):	4 (Mode 1), 3 (Mode 2), 12 (Mode 3), 3 (Mode 4), 6 (Mode 5)
DMX channels (TW variant):	2 (Mode 1), 3 (Mode 2)
DMX channels (TD, PW variant):	2 (Mode 1), 2 (Mode 2)
Power supply (CE):	Ambiane Power HP, Ambiane Power Rack
Operating ambient temp. range for primary power:	-20 °C / +40 °C (-4 °F / +104 °F)
Operating ambient temp. range for secondary power:	-20 °C / +70 °C (-4 °F / +158 °F)
Max. operating temperature:	+75 °C (167 °F)
Total heat dissipation:	191 BTU/h (calculated)
Cooling:	convection
Housing:	High Pressure Die-Cast Aluminium Body
Weight (without control unit) :	
Ambiane HP111 Recessed 20°	2.1 kg/ 4.6 lbs
Ambiane HP111 Recessed 40°	2.1 kg/ 4.6 lbs
Ambiane HP111 Recessed 60°	2.0 kg/ 4.4 lbs
Ambiane HP111 Recessed 80°	2.0 kg/ 4.4 lbs
Mounting Method:	Recessed, via mounted brackets. Cut-Out Diameter: 133 mm / 5.24 in
IC rating:	Non-IC rated
Power connection	Connectors
DMX connection:	Connectors
DALI connection:	Connectors
LED unit connection:	Connector
Protection factor (CE):	IP2X

Ambiane HP111 Recessed


Dimensions mm [inch]



Ambiane Hp111 Recessed 20°	H = 224 [8 13/16"] mm [inch]
Ambiane Hp111 Recessed 40°	H = 227 [8 15/16"] mm [inch]
Ambiane Hp111 Recessed 60°	H = 210 [8 1/4"] mm [inch]
Ambiane Hp111 Recessed 80°	H = 194 [7 5/8"] mm [inch]

Ambiane HP111 Recessed


Control unit



Ambiane HP111 Recessed

Dimensions (version with yoke)

mm [inch]



Ambiane HP111 Recessed 20°	H = 244 [9 5/8"] mm [inch]
Ambiane HP111 Recessed 40°	H = 247 [9 3/4"] mm [inch]
Ambiane HP111 Recessed 60°	H = 230 [9 1/16"] mm [inch]
Ambiane HP111 Recessed 80°	H = 214 [8 7/16"] mm [inch]

Ambiane HP111 Recessed

Included items

- 1 x Ambiane HP111 Recessed
- 1 x Control unit
- 1 x Set of cable connectors
- 1 x User manual

Optional items


- Ambiane Power HP (P/N 10064073)
- Ambiane Power Rack (P/N 10063951)

7. Photometric diagrams


Fixture set at 3200K, primary power (standard operation), 20° beam angle

Absolute photometry
Luminaire luminous flux: 2015 lm
Power: 65.0 W
Luminous efficacy: 31.0 lm/W

Luminous emittance 1 / Polar LDC




Luminous emittance 1 / Cone diagram




Fixture set at 3200K, secondary power (emergency operation), 20° beam angle

Absolute photometry
Luminaire luminous flux: 640 lm
Power: 20.0 W
Luminous efficacy: 32 lm/W

Luminous emittance 1 / Polar LDC



Luminous emittance 1 / Cone diagram



8. Cleaning and maintenance

Disconnect from the mains before starting any maintenance work


Keep the fixture clean, especially light source and the ribbed heat sink.
Maintenance and service operations are only to be carried out by a qualified person.
Should you need any spare parts, please use ROBE OEM parts.

8.1 Software update

The fixture has to be connected to power during software update.


Software update by means of the Robe Uploader

The ROBE Uploader is a software for automatized software update of Robe and Anolis fixtures. It can take advantage of RDM support.



Ambiane HP111 Recessed

The fixtures have to be connected in a daisy-chain (max. 32 fixtures) and via the Robe Universal Interface/Robe Universal Interface WTX and a USB cable connected to the control PC with the Robe Uploader running. The fixtures have to be connected to power. The control PC should be connected to the Internet.



The Robe Uploader software and user manual is available at <https://www.robe.cz/robe-uploader/>

If you do the software update by means of the Robe Uploader, switching fixtures to the update mode (and from the update mode) is made automatically.

Note: The Robe Uploader software cannot be used if fixtures are connected by means of DALI connection.

8.2 Disposing of the product

To preserve the environment please dispose or recycle this product at the end of its life according to the local regulations and codes.

Specifications are subject to change without notice

February 16, 2024

Made in CZECH REPUBLIC by ROBE LIGHTING s.r.o. Palackeho 416/20 CZ 75701 Valasske Mezirici